

Accessories: WSync dongle

DONGLE FOR WIRELESS CONFIGURATION OF VAS BOARDS



WSYNC-RJ



Dongle for wireless configuration of boards compatible with the WSync™ system RJ-25 plug

WSync allows wireless configuration and maintenance of VAS boards with the tip of your fingers, using either a tablet or a smartphone with Bluetooth and the free TSec App. By allowing the tuning of the configuration parameters directly where each vibration detector is installed, as opposed to where the analysis board is located, installation time and costs can be dramatically reduced, at the same time enhancing the quality and security of the system.

WSync is based on a proprietary accessory dongle that enables wireless operation of VAS boards. The dongle has been engineered so that it is used only during the initial or periodic configuration (maintenance) of the boards. In other words, it becomes one of the tools of the trade for security professionals.

WSync uses long range Bluetooth as a transmission means, and it has an indoor range of up to 15 meters.

Ordering guide

DONGLE	COMPATIBILITY	PACKAGING
WSYNC-RJ-A	Bluetooth 2 or above, Android 3.1 or above	1 dongle
WSYNC-RJ-I	Bluetooth 4, iOS 8 or above	